



Ghost Cord® Cordless Pad & Monitor Instructions:

Set-Up Instructions


1. Insert 9V battery into Ghost Cord® Cordless monitor. With the pad transmitter insert in hand, press and hold the "learn" button (button above battery). Monitor will beep 3 times to indicate programming mode.



2. Switch on pad transmitter unit. If programming is successful, monitor will sound one long beep and programming is complete. Make sure LED light on pad transmitter insert is blinking every 8 seconds, indicating pad transmitter is functioning. Open neck of cordless pad and connect pad transmitter insert. Place pad transmitter into neck of pad and close opening.




3. Put pressure on the Ghost Cord® Cordless pressure pad to program the Ghost Cord® Cordless monitor to work with the Ghost Cord® Cordless pressure pad. Monitor will beep two times to indicate programming of pressure pad and monitor is successful. Releasing pressure on pad will cause monitor to alarm; press reset button to silence alarm.




4. When pressure pad needs to be replaced, remove transmitter insert from neck of pad. Slide switch on side of pad transmitter insert to "off" mode and store for use with a new cordless pressure pad.

Troubleshooting Instructions


1. Check the lights on the front of the monitor. The "Status/In Use" Light should be blinking to indicate pressure pad is still talking to the monitor. If "Check Pad" Light is blinking, the pad is not within range of the monitor and needs to be placed closer to the monitor (within 40 ft).



2. Make sure that the pad transmitter insert is switched on and the LED light on the pad transmitter insert is blinking every 8 seconds. This indicates that the pad transmitter is functioning properly. If transmitter light is not blinking but pad transmitter insert is switched on, call your distributor.



3. Check power supply. A chirping monitor indicates battery needs replacing. Make sure your monitor has a charged battery by changing out the battery with a new battery. Or, if you are using an AC adapter, make sure the adapter is plugged into a power outlet.



4. Call your distributor to troubleshoot via telephone. Make sure both the pressure pad and the monitor malfunctioning are with you at the time of the phone call.